

Quick assembly instructions  
for DS / AKU locator

**DS locate**

PASSENGER / DELIVERY CAR

**1.**

Open the hood of the car and find the battery. To mount the locator to the battery, use the wrench that is included in the kit.



**2.**

Wipe the mounting area on the battery with the included disinfectant wipe to clean the place before sticking the locating device.



**3.**

Connect the DS/AKU locator to the battery clamps.



## 4.

Remember to connect red wire to the plus on the car battery.




**5.**

Stick the DS/AKU device to the battery with the double-sided tape on the bottom of the device.

**6.**

Correct installation is confirmed by a green LED.



**The correctness of the device installation is signaled by LED diodes, the statuses of which are indicated below:**

- The LEDs are off: no power to the device.
- The "Status LED" flashes about once a second and the "Navigate LED" is lit continuously - the device is communicating with the system, but is not locating.
- The "Status LED" is lit steadily and the "Navigate LED" flashes approximately once every second - the device has acquired a track of but is unable to communicate with the system.
- The Status LED "and the" Navigate LED "flash approximately once per second - the device is working properly.
- Status LED "and" Navigate LED "flash very fast - device is updating its software.



In order to verify the correctness of the device installation and receiving alerts from e-TOLL system, log in to the **DS Locate** application. You can download it for free from the **Google Play** or **AppStore**.



A video of the assembly of the device can be found here:  
**[bit.ly/Montaz-AKU](https://bit.ly/Montaz-AKU)**

Regulations for the provision of location services based on the DS Locate system and the rental or sale of devices available at [www.datasystem.pl](http://www.datasystem.pl)

#### **Data System Group**

ul. abpa A. Baraniaka 88 B  
61-131 Poznań | Poland  
t. + 48 61 62 63 000  
[biuro@datasystem.pl](mailto:biuro@datasystem.pl)

#### **Tech Support**

Mon. - Fri. 8.00 - 18.00  
Sat. 8.00 - 15.00  
[pomoc.techniczna@datasystem.pl](mailto:pomoc.techniczna@datasystem.pl)

[www.datasystem.pl](http://www.datasystem.pl)